


Landing Zone Safety and Security



- DO NOT ALLOW ANYONE TO APPROACH THE AIRCRAFT without permission from the pilot or a crewmember
- SPECTATORS MUST STAY AT LEAST 150 FEET FROM THE AIRCRAFT




- RESPONDERS AND THEIR VEHICLES MUST STAY AT LEAST 50 FEET FROM THE AIRCRAFT
- Crew may assign personnel to help carry the stretcher to the aircraft
- Exit the same direction which you approached the aircraft





Landing Zone Safety and Security





Landing Zone Setup Alternate Landing Zone Setup